



Customer Approved by:

REV	DESCRIPTION	DESIGN	DATE
A	1'ST DEGIN	JAVEN	Dec-29-2023
B	2'ED DEGIN	JAVEN	Feb-12-2025
C			
D			



CON2


PIN NO.	SIGNAL
1	GND
2	GND
3	5V
4	5V
5	TX
6	RX
7	RESET
8	BUSY/SDCD
9	SD_CS
10	SD_CLK
11	SD_DO
12	SD_DI
13	VBAT
14	BUZZER
15	DM
16	DP
17	CANRX
18	CANTX
19	GND
20	GND

CON3

PIN NO.	SIGNAL
1	GND
2	5V
3	RX
4	TX

NOTE:

- 1: If the display module has a PCBA, please fix SW1 in the DEBUG state for UART debugging. If the display module is FOG, SW1 is used as the USB port and UART debugging switch.
- 2: If you need to burn the ER-TFTS028-4, ER-TFTS032-3, ER-TFTS035-6 module MCU program or FLASH program, switch SW1 to the ON state and plug in the USB to enter the burning state. Switch to OFF state during normal operation
- 3: Unit: mm


旭日东方科技有限公司
EASTRISING TECHNOLOGY CO.,LTD
 Web: www.buydisplay.com Email: sales@buydisplay.com

APPROVALS	DATE	MODEL NUMBER :	GENERAL TOL :	UNITS
APP		Uart Display Debug Board	SCALE :	MM
CHK			N.T.S.	
DWN	JIM	DO NOT SCALE THIS DRAWING	PROJECTION	SHEET: 1