TFT Display Module to Raspberry pi (4-Wire SPI Interface)



== How to use ==

1, Install the C libraries of bcm2835, see: http://www.airspayce.com/mikem/bcm2835/
2, Change the current directory to where the Makefile and oled.c file located.
3, Clean the file with: make clean
4, Compile the file with: make
5, Run the demo with: sudo ./tft

REV.	DESCRIPTION OF MODIFY	MODIFY BY	DATE
A0	1'ST DESIGN	JIM	09/Jan/2024
A1			

Title: EASTRISING TECHNOLOGY CO.,LTD. www.buydisplay.com		
Size: A	Number: ER-TFTM0.85-1 (4-Wire SPI Interface)	Revision: A0
Date: 09/Jan/2024	Sheet of: 1	
File	Drawn By: Javen	